

Arduino Project Reference Pack

- pinMode(pin, mode): set input/output
- digitalWrite(pin, value): set HIGH/LOW
- analogRead(pin): read sensor value
- delay(ms): wait in milliseconds
- Serial.begin(baud): start serial monitor
- Common sensors: Ultrasonic, IR, DHT11
- Use resistors and check voltage limits!