



The dip switches are for physically setting a board "ID" or I2C address so that the software knows which board it's dealing with.

$$(14.4V * 2) * 10K / (10K + 60.4K) = 4.09V$$

$$30A * 0.001ohm * 100V/V = 3V$$