

Default Settings for the Sound Settings

Waveform List

Internal A

No.	Wave Name	Type	No.	Wave Name	Type	No.	Wave Name	Type	No.	Wave Name	Type	No.	Wave Name	Type
1	Ac Piano1 A	L	52	Nylon Gtr A	L	103	Syn Gtr B	L	154	MC-202 Bs B	L	205	Cello A	L
2	Ac Piano1 B	L	53	Nylon Gtr B	L	104	Syn Gtr C	L	155	MC-202 Bs C	L	206	Cello B	L
3	Ac Piano1 C	L	54	Nylon Gtr C	L	105	Harp 1A	L	156	Flute 1A	L	207	Cello C	L
4	Ac Piano2 pA	L	55	6-Str Gtr A	L	106	Harp 1B	L	157	Flute 1B	L	208	ST.Strings-R	L
5	Ac Piano2 pB	L	56	6-Str Gtr B	L	107	Harp 1C	L	158	Flute 1C	L	209	ST.Strings-L	L
6	Ac Piano2 pC	L	57	6-Str Gtr C	L	108	Banjo A	L	159	Blow Pipe	L	210	MonoStringsA	L
7	Ac Piano2 fA	O	58	Gtr Harm A	L	109	Banjo B	L	160	Bottle	L	211	MonoStringsC	L
8	Ac Piano2 fB	O	59	Gtr Harm B	L	110	Banjo C	L	161	Shakuhachi	L	212	Pizz	O
9	Ac Piano2 fC	O	60	Gtr Harm C	L	111	Sitar A	L	162	Clarinet A	L	213	JP Strings1A	L
10	Piano Thump	O	61	Comp Gtr A	L	112	Sitar B	L	163	Clarinet B	L	214	JP Strings1B	L
11	Piano Up TH	O	62	Comp Gtr B	L	113	Sitar C	L	164	Clarinet C	L	215	JP Strings1C	L
12	MKS-20 P3 A	L	63	Comp Gtr C	L	114	Dulcimer A	L	165	Oboe mf A	L	216	JP Strings2A	L
13	MKS-20 P3 B	L	64	Comp Gtr A+	L	115	Dulcimer B	L	166	Oboe mf B	L	217	JP Strings2B	L
14	MKS-20 P3 C	L	65	Mute Gtr 1	L	116	Dulcimer C	L	167	Oboe mf C	L	218	JP Strings2C	L
15	SA Rhodes 1A	L	66	Mute Gtr 2A	L	117	Shamisen A	L	168	Sop.Sax mf A	L	219	Soft Pad A	L
16	SA Rhodes 1B	L	67	Mute Gtr 2B	L	118	Shamisen B	L	169	Sop.Sax mf B	L	220	Soft Pad B	L
17	SA Rhodes 1C	L	68	Mute Gtr 2C	L	119	Shamisen C	L	170	Sop.Sax mf C	L	221	Soft Pad C	L
18	SA Rhodes 2A	L	69	Pop Strat A	L	120	Koto A	L	171	Alto Sax 1A	L	222	Fantasyynth A	L
19	SA Rhodes 2B	L	70	Pop Strat B	L	121	Koto B	L	172	Alto Sax 1B	L	223	Fantasyynth B	L
20	SA Rhodes 2C	L	71	Pop Strat C	L	122	Koto C	L	173	Alto Sax 1C	L	224	Fantasyynth C	L
21	E.Piano 1A	L	72	Jazz Gtr A	L	123	Pick Bass A	L	174	Tenor Sax A	L	225	D-50 HeavenA	L
22	E.Piano 1B	L	73	Jazz Gtr B	L	124	Pick Bass B	L	175	Tenor Sax B	L	226	D-50 HeavenB	L
23	E.Piano 1C	L	74	Jazz Gtr C	L	125	Pick Bass C	L	176	Tenor Sax C	L	227	D-50 HeavenC	L
24	E.Piano 2A	L	75	JC Strat A	L	126	Fingerd Bs A	L	177	Bari.Sax f A	L	228	Fine Wine	L
25	E.Piano 2B	L	76	JC Strat B	L	127	Fingerd Bs B	L	178	Bari.Sax f B	L	229	D-50 Brass A	L
26	E.Piano 2C	L	77	JC Strat C	L	128	Fingerd Bs C	L	179	Bari.Sax f C	L	230	D-50 Brass B	L
27	E.Piano 3A	L	78	JC Strat A+	L	129	E.Bass	L	180	Harmonica A	L	231	D-50 Brass C	L
28	E.Piano 3B	L	79	JC Strat B+	L	130	Fretless A	L	181	Harmonica B	L	232	D-50 BrassA+	L
29	E.Piano 3C	L	80	JC Strat C+	L	131	Fretless B	L	182	Harmonica C	L	233	DualSquare A	L
30	MK-80 EP A	L	81	Clean Gtr A	L	132	Fretless C	L	183	Chanter	L	234	DualSquare C	L
31	MK-80 EP B	L	82	Clean Gtr B	L	133	UprightBs 1	L	184	Tpt Sect. A	L	235	DualSquareA+	L
32	MK-80 EP C	L	83	Clean Gtr C	L	134	UprightBs 2A	L	185	Tpt Sect. B	L	236	Pop Voice	L
33	D-50 EP A	L	84	Stratus A	L	135	UprightBs 2B	L	186	Tpt Sect. C	L	237	Syn Vox 1	L
34	D-50 EP B	L	85	Stratus B	L	136	UprightBs 2C	L	187	Trumpet 1A	L	238	Syn Vox 2	L
35	D-50 EP C	L	86	Stratus C	L	137	Slap Bass 1	L	188	Trumpet 1B	L	239	Voice Aahs A	L
36	Celesta	L	87	OD Gtr A	L	138	Slap & Pop	L	189	Trumpet 1C	L	240	Voice Aahs B	L
37	Music Box	L	88	OD Gtr B	L	139	Slap Bass 2	L	190	Trumpet 2A	L	241	Voice Aahs C	L
38	Clav 1A	L	89	OD Gtr C	L	140	Slap Bass 3	L	191	Trumpet 2B	L	242	Voice Oohs1A	L
39	Clav 1B	L	90	OD Gtr A+	L	141	Jz.Bs Thumb	L	192	Trumpet 2C	L	243	Voice Oohs1B	L
40	Clav 1C	L	91	Heavy Gtr A	L	142	Jz.Bs Slap 1	L	193	HarmonMute1A	L	244	Voice Oohs1C	L
41	Organ 1	L	92	Heavy Gtr B	L	143	Jz.Bs Slap 2	L	194	HarmonMute1B	L	245	Voice Oohs2A	L
42	Jazz Organ 1	L	93	Heavy Gtr C	L	144	Jz.Bs Slap 3	L	195	HarmonMute1C	L	246	Voice Oohs2B	L
43	Jazz Organ 2	L	94	Heavy Gtr A+	L	145	Jz.Bs Pop	L	196	Trombone 1	L	247	Voice Oohs2C	L
44	Organ 2	L	95	Heavy Gtr B+	L	146	Syn Bass A	L	197	French 1A	L	248	Voice Breath	L
45	Organ 3	L	96	Heavy Gtr C+	L	147	Syn Bass C	L	198	French 1C	L	249	Male Ooh A	L
46	Organ 4	L	97	PowerChord A	L	148	Mini Bs 1A	L	199	F.Horns A	L	250	Male Ooh B	L
47	Rock Organ	L	98	PowerChord B	L	149	Mini Bs 1B	L	200	F.Horns B	L	251	Male Ooh C	L
48	Dist. Organ	L	99	PowerChord C	L	150	Mini Bs 1C	L	201	F.Horns C	L	252	Org Vox A	L
49	Rot.Org Slw	L	100	EG Harm	L	151	Mini Bs 2	L	202	Violin A	L	253	Org Vox B	L
50	Rot.Org Fst	L	101	Ct.FretNoise	O	152	Mini Bs 2+	L	203	Violin B	L	254	Org Vox C	L
51	Pipe Organ	L	102	Syn Gtr A	L	153	MC-202 Bs A	L	204	Violin C	L	255	Vox Noise	L

L: Loop Waveform
O: One-shot Waveform

* For important information about the difference between loop and one-shot sounds, and how they are edited, see Chapter 1, "5. Concerning Tone Editing" (p. 26)