


FLSUN S1 - FIRMWARE UPDATE WITH USB


Follow the steps below to update your S1 firmware to the latest version using a USB flash drive.

NOTE: It is recommended to use the USB Drive provided with the machine to perform the update.



1. Clear all files from the USB Drive to facilitate a seamless firmware flashing process.



2. Transfer all files from the zip package provided into the USB Drive, then safely eject it.



3. With the machine powered off, insert the USB Drive into the USB port, then press and hold the button for 1.5 seconds to power on the machine and initiate the update process.



4. Once the progress bar is fully loaded, the system will automatically enter. At this point, you can safely remove the USB stick.



5. Verify the version number to confirm that the update has been successfully completed.



6. If there's a new version available, you can upgrade directly online using OTA (Over-the-Air) updates. Instructions for the online upgrade procedure can be found on the FLSUN Wiki page.

NOTE: If resonance compensation and leveling were conducted before this update, recalibration is unnecessary for this update.