

code name	windows	mac	keycode	code name	windows	mac	keycode	code name	windows	mac	keycode
KEY_NONE			000	KEY_F1	F1	F1	058	KEY_EMAIL	email	(x)	116
KEY_A	a	a	004	KEY_F2	F2	F2	059	KEY_WWW_SEARCH	web search	(x)	117
KEY_B	b	b	005	KEY_F3	F3	F3	060	KEY_WWW_HOME	web home	(x)	118
KEY_C	c	c	006	KEY_F4	F4	F4	061	KEY_WWW_BACK	web back	(x)	119
KEY_D	d	d	007	KEY_F5	F5	F5	062	KEY_WWW_FORWARD	web forward	(x)	120
KEY_E	e	e	008	KEY_F6	F6	F6	063	KEY_WWW_STOP	web stop	(x)	121
KEY_F	f	f	009	KEY_F7	F7	F7	064	KEY_WWW_REFRESH	web refresh	(x)	122
KEY_G	g	g	010	KEY_F8	F8	F8	065	KEY_WWW_FAVORITE	web favorite	(x)	123
KEY_H	h	h	011	KEY_F9	F9	F9	066	KEY_NEXT_TRK	next track	next track	124
KEY_I	i	i	012	KEY_F10	F10	F10	067	KEY_PREV_TRK	prev track	prev track	125
KEY_J	j	j	013	KEY_F11	F11	F11	068	KEY_STOP	stop	stop	126
KEY_K	k	k	014	KEY_F12	F12	F12	069	KEY_PLAY	play	play	127
KEY_L	l	l	015	KEY_PRNSCR	print screen	F13	070	KEY_MUTE	mute	mute	128
KEY_M	m	m	016	KEY_SCRLCK	scroll lock	F14	071	KEY_VOL_UP	volume up	volume up	129
										volume down	
KEY_N	n	n	017	KEY_PAUSE	pause	F15	072	KEY_VOL_DOWN	volume down	down	130
KEY_O	o	o	018	KEY_INSERT	insert	Help	073	KEY_MEDIA	media	(x)	131
KEY_P	p	p	019	KEY_HOME	home	home	074	KEY_CALC	calculator	(x)	132
KEY_Q	q	q	020	KEY_PGUP	page up	page up	075	KEY_MYCOM	my computer	(x)	133
KEY_R	r	r	021	KEY_DEL	delete	delete	076	KEY_HANJA	한자	(x)	142
KEY_S	s	s	022	KEY_END	end	end	077	KEY_HANGLE	한/영	(x)	143
KEY_T	t	t	023	KEY_PGDN	page down	page down	078				
KEY_U	u	u	024	KEY_RIGHT	right	right	079				
KEY_V	v	v	025	KEY_LEFT	left	left	080	// PS/2 only			
KEY_W	w	w	026	KEY_DOWN	down	down	081	KEY_POWER	power	(x)	113
KEY_X	x	x	027	KEY_UP	up	up	082	KEY_SLEEP	sleep	(x)	114
KEY_Y	y	y	028	KEY_NUMLOCK	num lock	num lock	083	KEY_WAKE	wake	(x)	115
KEY_Z	z	z	029	KEY_KP_SLASH	pad /	pad /	084	KEY_SCREENSAVE	screensave	(x)	134
KEY_1	1	1	030	KEY_KP_AST	pad *	pad *	085	KEY_REC	rec	(x)	135
KEY_2	2	2	031	KEY_KP_MINUS	pad -	pad -	086	KEY_REWIND	rewind	(x)	136
KEY_3	3	3	032	KEY_KP_PLUS	pad +	pad +	087	KEY_MINIMIZE	minimize	(x)	137
KEY_4	4	4	033	KEY_KP_ENTER	pad enter	pad enter	088	KEY_EJECT	eject	(x)	138
KEY_5	5	5	034	KEY_KP_1	pad 1	pad 1	089				
KEY_6	6	6	035	KEY_KP_2	pad 2	pad 2	090	// macro			
KEY_7	7	7	036	KEY_KP_3	pad 3	pad 3	091	KEY_MAC1	macro 01	macro 01	201
KEY_8	8	8	037	KEY_KP_4	pad 4	pad 4	092	KEY_MAC2	macro 02	macro 02	202
KEY_9	9	9	038	KEY_KP_5	pad 5	pad 5	093	KEY_MAC3	macro 03	macro 03	203
KEY_0	0	0	039	KEY_KP_6	pad 6	pad 6	094	KEY_MAC4	macro 04	macro 04	204
KEY_ENTER	enter	enter	040	KEY_KP_7	pad 7	pad 7	095	KEY_MAC5	macro 05	macro 05	205
KEY_ESC	esc	esc	041	KEY_KP_8	pad 8	pad 8	096	KEY_MAC6	macro 06	macro 06	206
KEY_BKSP	backspace	backspace	042	KEY_KP_9	pad 9	pad 9	097	KEY_MAC7	macro 07	macro 07	207
KEY_TAB	tab	tab	043	KEY_KP_0	pad 0	pad 0	098	KEY_MAC8	macro 08	macro 08	208
KEY_SPACE	space	space	044	KEY_KP_DOT	pad .	pad .	099	KEY_MAC9	macro 09	macro 09	209
KEY_MINUS	_	_	045	KEY_Europe2			100	KEY_MAC10	macro 10	macro 10	210
KEY_EQUAL	=+	=+	046					KEY_MAC11	macro 11	macro 11	211
KEY_LBR	[{	[{	047	KEY_APPS	context	(x)	101	KEY_MAC12	macro 12	macro 12	212
KEY_RBR	}]	}]	048								
KEY_BKSLASH	\	\	049	KEY_LCTRL	left control	left control	103				
KEY_Europe1			050	KEY_LSHIFT	left shift	left shift	104	// etc			
KEY_COLON	::	::	051	KEY_LALT	left alt	option	105	KEY_LED_DOWN	reduce LED brightness		249
									increase LED brightness		
KEY_QUOTE	""	""	052	KEY_LGUI	left win	command	106	KEY_LED_UP	NORMAL		250
KEY_HASH	~	~	053	KEY_RCTRL	right control	right control	107	KEY_NOR	FN2 (toggle)		251
KEY_COMMA	,<	,<	054	KEY_RSHIFT	right shift	right shift	108	KEY_BEYOND_FN	full LED		252
KEY_DOT	>	>	055	KEY_RALT	right alt	option	109	KEY_LED	FN		253
KEY_SLASH	/?	/?	056	KEY_RGUI	right win	command	110	KEY_FN			254
KEY_CAPS	caps lock	caps lock	057								