


For compiling in Windows, Arduino 1.0.5 or 1.0.6 is preferred, although arduino beta 1.5 may also work. Download the windows "installer" version from <http://arduino.cc> and follow its default installation.


From the arduino program you can see the "sketchbook location", that is where the project files are installed for you. **Click "FILE / PREFERENCES"**.

Linux usually uses "~/user/sketchbook":


Versions of Windows may use a "sketchbook" or a "arduino" folder. I have a WinXP install that uses "C:\Arduino" and a Win7-64 install that uses "C:\Users\Brian\Documents\Arduino".



my LINUX





my WIN-XP



my WIN-7

You must place **ALL** of the arduino files into the folder "VirtGPIO" inside your sketchbook area. **Nothing goes into the "libraries" area:**



Re-start the arduino program, find the VirtGPIO project in the sketchbook (Click FILE / SKETCHBOOK). Set Board type (TOOLS / BOARD) to match your arduino type (must be a 328 type, eg UNO or Nano). It should compile cleanly.