


A13 is used to activate the CHR ROM by putting the CE pin low. This means that the CHR ROM is activated whenever address 0x0000 - 0x1FFF appears on the bus.


PRG-ROM	16kB
CHR-ROM	8kB



A13 is used to activate the CHR ROM by putting the CE pin low. This means that the CHR ROM is activated whenever address 0x0000 - 0x1FFF appears on the bus.

Mirroring Type	H Jumper	V Jumper
Horizontal	Open	Short
Vertical	Short	Open

PRG-ROM	32kB
CHR-ROM	8kB



PRG-ROM	128kB
PRG-RAM	None
CHR-ROM	None
CHR-RAM	8kB

