



# MultiWii 1pre7 Stick Configuration

Mode 2


Motor Arm




Motor Arm on TRI




Motor Disarm




Motor Disarm on TRI




Calibration Acro Gyro



Calibration Stable ACC  
(disarm Motor first)




Trim ACC




(move right stick from center  
and back for each click –  
LED blinks once per click)

# LCD – Configuration Mode


Enter  
(disarm Motor first)




Select Param



Change Value



Save and Exit



This work is licensed under the

Creative Commons Attribution-NonCommercial-ShareAlike 3.0  
Unported License.

To view a copy of this license, visit  
<http://creativecommons.org/licenses/by-nc-sa/3.0/> or send a letter to  
Creative Commons, 171 Second Street, Suite 300,  
San Francisco, California, 94105, USA.

Document 2011-03-03

Version 0.577

(lookup Euler-Macheyoni constant)  
A Product made by Hamburger