


Note that RST and CLK come IN FROM the board  
so you can use the clock gen / button there



Sheet: /  
File: tt02-multiplexed-schematic.kicad\_sch

**Title:**

Size: A4  
KiCad E.D.A. kicad 7.0.10

Date:

**Rev:**  
Id: 1/1