



Thank you for using ANE's wi-fi Auto Reboot. This software uses a son off to reboot your router automatically when the wi-fi goes down. lets get started.

1.

Wire up your sonoff with an extension cable. If you don't know how we found a good article at <https://tinyurl/ANE-sonoff-wifi>. Then connect the router to the extension cable - DO NOT ATTEMPT TO DO THIS DIRECTLY TO THE ROUTER!

2.

Open the file sonoff.ino , then find the line

```
#define ssid ("NETWORK")
```

And double click NETWORK. then type your network name. Then find the line (it won't be very hard, it's right under it) and find

```
#define ssidpw ("PASSWORD")
```

Again, double click, then type the password to your network.

:D one! Feel free to remix the code, share the code (Your version included) and please give us credit! Have a nice day!

-Your friends at ANE