



INVALID Active low output that indicates if no valid RS-232 levels are present on any receiver input.

EN Active low receiver enable control; doesn't disable ROUTB outputs.

SHDN Active low input to shut down transmitters and on-board power supply, to place device in low power mode.

FORCEOFF Active low to shut down transmitters and on-chip power supply. This overrides any automatic circuitry and FORCEON

FORCEON Active high input to override automatic power-down circuitry thereby keeping transmitters active (FORCEOFF must be high)