

RC522 RFID READER

MISO
MOSI
SCK
SDA/SS

3.3V
RST
GND

LED PUSH BUTTON

CANCEL LIGHT
CANCEL BUTTON
GND

+12V
COIN
GND

CH-92x COIN MECH

GND +12V POWER INPUT

I2C LCD

SCL
SDA
VCC +5V
GND

