

HAIR – CARE

It,s Your Time To Shine



BAB6689U

BaByliss[®] PRO

S T Y L I S T T O O L S

GTIonic II

Compact yet powerful, this perfectly balanced BaByliss PRO GTIonic II dryer combines ionic and ceramic technology to leave hair soft, shiny and manageable.

Features:

- 2000W
- Combined ionic and ceramic technology
- High performance AC motor
- 6 heat/speed settings
- Cold shot
- Concentrator nozzle
- Comfort grip
- 2.7m salon length power cord
- Removable rear filter
- Hanging loop

SAFETY CAUTIONS

- This appliance should only be used as described within this instruction booklet. Please retain for reference.

WARNING! Polythene bags over a product may be dangerous. To avoid danger of suffocation, keep this wrapper away from babies and children. This bag is not a toy.

- **UK Only:** This appliance must not be used in the bathroom. If using the appliance in a bathroom, unplug after use as the proximity of water can be dangerous even if the appliance is switched off. For



additional protection the installation of a residual current device RCD) with a rated residual operating current not exceeding 30mA is advisable in the electrical circuit supplying the bathroom. Ask your installer for advice.

WARNING! Do not use this appliance near water contained in basins, bathtubs or other vessels.

- Do not use this appliance in the bathroom.
- Do not immerse the appliance into water or other liquids.
- Never look directly into the barrel of the hairdryer when it is switched on.
- Always inspect the appliance before use for noticeable signs of damage. Do not use if damaged, or if the appliance has been dropped. In the event of damage, contact the Conair Customer Care Line (refer to UK After Sales Service section for further information).
- Do not use the appliance if the lead is damaged. In the event of damage, discontinue use immediately. Return the appliance to the Conair Service Centre (refer to UK After Sales Service section for further information).
- Do not leave the appliance unattended when switched on or plugged in.
- This appliance is equipped with a safety thermostat. In the event of overheating, the appliance will run hot and cold intermittently. In the event of this happening, turn the dryer off, unplug from the mains and allow to cool for 15 minutes. Before using again, ensure the rear filter is clear of hair and other debris. Plug in and switch on. If the appliance continues to overheat (i.e. element glows red intermittently), discontinue use immediately, switch off and unplug. Contact the Conair Customer Care Line (refer to UK After Sales Service section for further information).
- Take care that the air vents do not become blocked when in use. Ensure the rear filter is clear of hair and other debris before use.

- Do not place the appliance on any surface whilst in operation.
- Take care to avoid the hot surfaces of the appliance coming into direct contact with the skin, in particular the ears, eyes, face and neck.
- Careful adult supervision is required when this appliance is used on or near children. Do not use on very young children.”
- This appliance should not be used, cleaned or maintained by children. Keep out of the reach of children.
- This appliance should not be used by adults whose reduced physical, sensory or mental capabilities, or whose lack of experience and knowledge, might cause a hazard, unless they have been correctly instructed to understand the safe use and hazards involved and are adequately supervised.
- Allow appliance to cool before storing away.
- After use, do not coil the lead around the appliance as this may cause damage to the lead. Instead, coil the lead loosely by the side of the appliance.
- This appliance complies with the requirements of Directives 2004/108/CEE (Electromagnetic Compatibility) and 2006/95/CE (Electrical Safety of Domestic Appliances). amended by Directive 93/68/EEC (CE Marking).

OPERATING INSTRUCTIONS

- Towel dry and detangle hair.
- Plug the appliance into a suitable mains socket.
- Select the required heat and speed settings.
- After use, switch off and unplug the appliance.
- Allow to cool before storing away.

IMPORTANT: Always keep the rear of the appliance away from the hair during use to prevent it being drawn in through the rear air filter.

CLEANING & MAINTENANCE

To keep your hairdryer in the best possible condition and maintain optimum performance, please follow the steps below:

- Do not wrap the lead around the appliance, instead coil the lead loosely by the side of the dryer
- Always unplug after use
- Do not use the hairdryer at a stretch from the power point

Cleaning the filter

- Ensure the appliance is switched off, unplugged and cool
- Holding the handle of the appliance firmly twist the rear filter in an anticlockwise direction to remove
- Using a soft brush, clean any hair and other debris from the filter
- Replace the rear filter by twisting back into place
- To clean the outside of the hairdryer, wipe with a damp cloth. Make sure that no water enters the hairdryer and the hairdryer is completely dry before use

UK GARANTEE

This BaByliss PRO appliance is guaranteed for salon use for 6 months. This guarantee covers defects under normal use from date of purchase and ceases to be valid in the event of alteration or repair by unauthorised persons. If the appliance does not perform satisfactorily due to defects in materials or manufacture, it will be repaired or replaced through Conair UK After Sales Service. The Conair Group Ltd reserves the right to amend terms and specifications without prior notice.

This guarantee in no way affects your statutory rights.

UK AFTER SALES SERVICE

For further advice on using the appliance, contact the Conair Customer Care Line on 0870 5 133191 (09:00 to 17:00 Monday to Friday) or email your enquiry to ukinfo@conair.com


If you should need to return your appliance to us please send it to the following address:

Customer Care Centre,
Conair Logistics
Unit 4
Revolution Park
Buckshaw Avenue
Buckshaw Village
Chorley
PR7 7DW

Please enclose your name and address, together with a copy of proof of purchase and details of the fault.

SAFE DISPOSAL



The  symbol on the product or on its packaging indicates that this product may not be treated as household waste. Instead it should be handed to an appropriate collection point for the recycling of Electrical and Electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. For more detailed information about the recycling of this product, please contact your local council office or your household waste disposal service.


UK WIRING INSTRUCTIONS

The wires in the mains lead are coloured in accordance with the following code:

BLUE = NEUTRAL

BROWN = LIVE

As the colours in the wire of the mains lead of this appliance may not correspond with the colour marking identifying the terminals on your plug, proceed as follows:

- The wire which is coloured BLUE must be connected to the terminal which is marked with the letter N or coloured black.
- The wire which is coloured BROWN must be connected to the terminal which is marked with the letter L or coloured red.
- Neither core should be connected to the earth terminal of a three pin plug marked with the letter E or  or is coloured green or green and yellow.

With this appliance, if a 13amp plug is used a 13amp fuse should be fitted. If any other type of plug is used, a 10 amp fuse must be fitted either in the plug or at the distribution board.

