

ENABLE VoLTE TO ENJOY QUALITY & SATISFYING CALLS

Find your phone model & follow these simple steps to activate now



These instructions are applicable to ALL device models, unless stated otherwise



iPhone

Your VoLTE will be
automatically enabled



**Supported from iPhone 6s and Apple Watch Series 3 onwards*

You can also activate it manually

Go to **Settings** >
Mobile Data



Select
Mobile Data Options



Select
Voice & Data





Enable
4G, VoLTE On






Your VoLTE will be
automatically enabled





You can also activate it manually


ColorOS 3.0 & 3.1 version




ColorOS 3.2 & above



ColorOS 5.0 & above





You can also activate it manually





Your VoLTE will be
automatically enabled



You can also activate it manually

Go to **Settings**



Select
**SIM Cards &
Mobile Networks**



Select
Celcom SIM



Turn On
Use VoLTE







realme

Your VoLTE will be
automatically enabled





You can also activate it manually





Your VoLTE will be
automatically enabled



You can also activate it manually

Go to **Settings**



Select
Mobile Network




Select
Mobile Data




Turn On
VoLTE Calls





You can also activate it manually





You can also activate it manually

