

**1) What are the actions done by EcuM in the preOS Sequence?**

- a. Callout EcuM\_AL\_SetProgrammableInterrupts
- b. Callout EcuM\_AL\_DriverInitZero
- c. Callout EcuM\_DeterminePbConfiguration
- d. Check consistency of configuration data
- e. Callout EcuM\_AL\_DriverInitOne
- f. Select default shutdown target
- g. Callout EcuM\_LoopDetection
- h. Start OS

**2) What are the actions done by EcuM in the preOS Sequence?**

- a. De-init BSW Mode Manager
- b. De-init BSW Scheduler
- c. Check for pending wakeup events
- d. Set RESET as shutdown target, if wakeup events are pending (default reset mode of *EcuMDefaultResetModeRef* (ECUC\_EcuM\_00205) will be used)
- e. ShutdownOS