



Hot Keys

Playlist

Ctrl+O

Open Playlist

Ctrl+S

Save Playlist

Ctrl+Alt+P

Playlist Properties

Ctrl+N

New Stream

Ctrl+D

Delete Stream

Ctrl+Shift+S

Settings

Editor

Ctrl+F

Find

Ctrl+Shift+F

Font

Ctrl+M

Add marker

Ctrl+Shift+M

Add slide marker

Ctrl+Shift+C

Add camera marker

Ctrl+Q

Update editor to current viewer position

Ctrl+PgUp

Previous stream

Ctrl+PgDn

Next stream

Ctrl+Up

Previous marker

Ctrl+Down

Next marker

Ctrl+Left

Decrease font size

Ctrl+Right

Increase font size

Ctrl+1

Change colour to white

Ctrl+2

Change colour to yellow

Ctrl+3

Change colour to green

Ctrl+4

Change colour to blue

Ctrl+5

Change colour to red

Ctrl+6

Change to all CAPS

Ctrl+7

Change to Sentence case



Hot Keys

Viewer Controls

Space / Alt+X

Alt+PgUp

Alt+PgDn

Alt+Up

Alt+Down

Alt+B

Alt+L

Alt+ Left & Right arrows

Alt+P

Alt+Z

Alt+Q

Alt+R

Alt+U

Alt+D

Alt+H

Alt+V

Play / Pause

Previous stream

Next stream

Previous marker

Next marker

Blackout

Logo

Adjust speed

Show mini-previewer

Show max-previewer

Update viewer

Refresh Viewer

Countup timer

Countdown timer

Flip Horizontally

Flip Vertically

Mouse Controls

Mouse wheel

Right click

Adjust speed

Play / Pause

Max-Previewer Controls

Mouse wheel

F2

Eyeline left click

ESC

Adjust speed / Scroll

Activate scroll

Play / Pause

Close max-previewer