



Prism Controls / Panel Wiring

Course and Fine Frequency controls
Wire the 'ears' of the two pots together




Sine Distortion




1V per octave CV Input



FM CV Input



Signal Outputs



Arrow denotes pin 1 on potentiometers
Jacks with sleeve can be terminated to spare GNDT pin