


탐색기를 이용하여 모든 파일을 보거나 삭제할 수 있다.



The screenshot shows a Windows File Explorer window. The left sidebar has the '내 PC' (This PC) section expanded, showing various drives and folders like '3D 개체', '다운로드', '문서', '바탕 화면', '사진', '음악', 'C System (C)', 'C Work (D)', 'C Data (E)', and 'MICROBIT (F)'. The main area displays a list of files and folders, including 'microbit-Untitled' which is highlighted. The right pane shows the details of the selected file, including its name, date modified, and type.







0% 완료



다운로드에서 MICROBIT (J:)(으)로 1개 항목 복사 중

0% 완료



이름: microbit-Untitled

남은 시간: 계산 중...

남은 항목: 1개(625KB)




간단히

38% 완료

다운로드에서 MICROBIT (J:)(으)로 1개 항목 복사 중

38% 완료



이름: microbit-Untitled

남은 시간: 계산 중...

남은 항목: 1개(369KB)



간단히