



SEND FOR REPAIR

1/3

VISIBLE ERRORS



Are there visible errors such as broken panel, button, goose neck, cover or water damage?



YES



NO

2/3

POWER ERRORS



Are there errors regarding no or low power, runtime, lights and charging?



Low runtime

No light

Only low light

No charging

Broken button?



YES



NO



Check indication light

Is the battery charging properly?

OK

Charge until full battery



YES



NO

STEP 3/3




3/3

CHARGING ERROR



Troubleshooting guide
when experiencing issues
regarding charging.






1/3

VISIBLE ERRORS







Is the product free from visible errors?
Such as broken panel, button, cable, cover or water damage?



2/3

POWER ERRORS

Are there errors regarding no or low power, runtime, lights and charging?



3/3

CHARGING SETUP

Troubleshooting setup guide when experiencing issues regarding charging.

