




Core




ESP




ESP_MODE




BUZZER




Input sensor




Input Switch




HX711




Gate Drivers




2Phase




5Phase




LED




RS232




Upload




POWER




Uart 5v




STM Boot Mode



XNOR



IO Peri 3v3



ETC

