




## Core






## ESP




## ESP\_MODE




## Gate Drivers




## 2Phase




## 5Phase




## HX711




## RS232




## Input sensor




## Input Switch



## STM Boot Mode



## BUZZER




## LED




## ETC


## Upload




## POWER



## Uart 5v



## XNOR



## IO Peri 3v3

