

| | | | |
|----------------|----------------|----------------|----------------|
| UPLINK ACTY | TEMP | UPLINK ACTY | TEMP |
| NO ATT | GIMBAL LOCK | NO ATT | GIMBAL LOCK |
| STBY | PROG | STBY | PROG |
| KEY REL | RESTART | KEY REL | RESTART |
| OPR ERR | TRACKER | OPR ERR | TRACKER |
| PRIO DISP | ALT | PRIO DISP | ALT |
| NO DAP | VEL | NO DAP | VEL |

| | | | |
|----------------|----------------|----------------|----------------|
| UPLINK ACTY | TEMP | UPLINK ACTY | TEMP |
| NO ATT | GIMBAL LOCK | NO ATT | GIMBAL LOCK |
| STBY | PROG | STBY | PROG |
| KEY REL | RESTART | KEY REL | RESTART |
| OPR ERR | TRACKER | OPR ERR | TRACKER |
| PRIO DISP | ALT | PRIO DISP | ALT |
| NO DAP | VEL | NO DAP | VEL |