



Copyright (C) 2019 John Winans		
This documentation describes Open Hardware and is licensed under the CERN OHL v. 1.2.		
You may redistribute and modify this documentation under the terms of the CERN OHL v.1.2. (http://ohwr.org/cernohl). This documentation is distributed WITHOUT ANY EXPRESS OR IMPLIED WARRANTY, INCLUDING OF MERCHANTABILITY, SATISFACTORY QUALITY AND FITNESS FOR A PARTICULAR PURPOSE. Please see the CERN OHL v.1.2 for applicable conditions		
If you chose to manufacture products based on this design, please notify me (see license section 4.2) via john@winans.org		
Sheet: /		
File: synch_counter_enable.sch		
Title: Synchronous Counter With Enable		
Size: User	Date: 2020-02-23	Rev: 1
KiCad E.D.A. kicad 5.1.5-52549c584ubuntu18.04.1		Id: 1/1