



Control



UP
DOWN
LEFT
RIGHT
FIRE
START
GND



COIN

ESP32 Bottom

