



R7 is CANBUS 120ohms termination resistor  
if it is not at the end of bus then please remove this resistor.

Centroid Connector	
Pin #	Func.
1	GND
2	IGN+
3	CONT0 / PB8
4	CONT1 / PB7
5	CONT2 / PB6
6	Burnout / PB5
7	CAN_H
8	CAN_L

GPIO	
Pin #	Func.
0	IO0 / PA
1	IO1 / PA
2	IO2 / PA
3	IO3 / PA

MCU PIN Map	
Pin #	Func.
PC14	LED_HeartBeat
PB4	LED_Continuity
PC15	CHARGE
PB9	nDISCHARGE
PC13	IGN0
PA12	CAN_TX
PA11	CAN_RX