

【Notes on “SiTCP.xdc” or “EDF_SiTCP.xdc”】

“SiTCP.xdc” or “EDF_SiTCP.xdc” must be located at the **bottom** in [Compile Order] tab of [Sources] view. Please refer to following procedure (figures) to change the order of XDC files.




Figure 1 “SiTCP.xdc” locates above top module’s XDC file




Figure 2 Click [Add Sources]




Figure 3 Select [Add or create constraints] and Click [Next]




Figure 4 Select "SiTCP.xdc" and click [Move down]




Figure 5 “SiTCP.xdc” moved down




Figure 6 Click [Finish]




Figure 7 "SiTCP.xdc" locates at the bottom of the XDC Files