


1

2

3

4



JTAG_TCK
JTAG_TDI
JTAG_TMS
JTAG_TDO
UARTHS_RX
UARTHS_TX

BOOT

Voltage of BANK0 : 3.3V



Voltage of BANK1 : 3.3V

Voltage of BANK2 : 3.3V

Voltage of BANK3 : 3.3V

Entry ISP mode:
BOOT(IO16) Pull low and then press Reset
IO4(UART RX) IO5(UART TX)

SPI0/1/3 only work in Master mode
SPI2 only work in Slave mode
Maximum rate: 45Mbps



SPI3支持XIP

