


User manual

1. Login choice screen:



a. Here the user has 2 options- to register:



b. Or to log in:




2. Main menu screen:




a. Here the user can log out, go to settings:




- i. From settings user can go to account info screen to view their email:




- ii. Theme choice screen:



iii. Demo screen



Controller: 

Enter Partner Address

Enter Preamble Value

200

Your Device Address: 8840

Start

Enter measured distance

Enter measured angle

Start

UWB

distance: Loading...

angle: Loading...

GYROSCOPE

X: -0.499

Y: 0.066

Z: -0.240

ACCELEROMETER

X: 0.763

Enter measured distance

Enter measured angle

Start

UWB

distance: Loading...

angle: Loading...

GYROSCOPE

X: -0.127

Y: -0.030

Z: 0.047

ACCELEROMETER

X: 0.770

Y: 6.462

Z: 8.476

GRAVITY

X: -0.661

Y: 5.193


Z: 5.299

FORWARD

-12.145

ROTATION

azimuth: 183°



b. Play now screen:




i. From here the user can generate a QR code:



ii. Or join a game by scanning a QR code



iii. After starting the game the view for both players will alternate between minigame screen:




iv. And the waiting screen:



c. Stats screen- view user's stats



d. Tutorial screen- view game rules



e. Minigame screen- play the minigame without playing the whole game.

