

Stick Gesture	Action
up,up,up	set bind flag
down,down,down	save bind
down,down,down	if no other gestures performed first, calibrate gyro
right,right,right	enter OSD menu
down,up,down	invert yaw (for props in/out)
right,right,down left,left,down	toggle aux channel