



Mesh Bag Replacement Instructions

- 1) Remove two small screws in EGO Grip
- 2) Where hoop frame exists the EGO Grip:
 - a. Take flat slotted screw driver and slide it between Grip and aluminum frame
- 3) Pry the two Grip halves apart
 - a. Apply constant pressure until two halves separate (pins on the interior will begin to “unzip”)
- 4) Remove 4 screws that hold hoop frame into aluminum core body
- 5) Remove hoop frame
- 6) Take old mesh bag off and restring hoop with new mesh bag
- 7) Insert hoop back into aluminum core body
- 8) Replace 4 screws (be sure not to over tighten / if over tightened run the risk of stripping aluminum threads)
- 9) Replace EGO Grip
 - a. Will have to use some pressure to get it to seat closed (small vice usually works well)
- 10) Replace two small screws at the top of EGO Grip