



ADDR. MULTIPLEXING & CAS SIGNALS GENERATION




FLIPPED SOCKETS (MEMORY ADDRESS BUS)




DATA OUTPUT BUFFER (ONBOARD)




DATA INPUT BUFFERS







CAS GENERATION



EXPANSION RAM





Expansion RAM		
P	Disabled	Enabled
1	OFF	ON
2	ON	OFF
3	OFF	ON
4	ON	OFF
5	OFF	ON
6	ON	OFF

Expansion RAM		
P	Disabled	Enabled
1	OFF	ON
2	ON	OFF
3	OFF	ON
4	ON	OFF
5	OFF	ON
6	ON	OFF
7	OFF	ON
8	ON	OFF

