


Install instructions for the ETAG RFIDuino by Jay Wilhelm (jwilhelm@ohio.edu)

URL Link for the board manager:


https://raw.githubusercontent.com/jaywilhelm/ArduinoCore-ETAGRFID/master/package_ETAGRFID_index.json

1) File->Preferences (paste the URL into 'Additional Boards Manager URLs:')




2) Tools -> Board: "xxxxxx" -> Boards Manager...


3) Scroll down to the bottom, click on ArduinoETAGRFIDcore, then click the 'Install' button in bottom right



4) After install check:



5) Select the "ETAG RFID" board...



6) Happy coding...

-Jay