


Motorized Conveyor

1. Prior to assembling the Conveyor into your Rokenbok world, we suggest you add the beam assembly to your Conveyor as shown. Once this beam is in place you can continue to assemble the Conveyor into any of your Rokenbok worlds.



ROKENBOK®
TOY COMPANY

*The Construction System
with Radio Control Action!*

WARRANTY

Rokenbok products are manufactured to meet stringent tests for quality, durability, reliability and safety. Our Radio Control Center and Control Pads are warranted against defects in material and workmanship for a lifetime to the original purchaser when used under normal operating conditions. All plastics, mechanics and other parts are warranted against defects in material and workmanship for a period of six months from the date of original purchase when used under normal operating conditions.

CUSTOMER SERVICE

Personalized help is just a quick e-mail or phone call away! You can reach our Customer Service Department at customerservice@rokenbok.com or call 1-888-4ROKBOK (1-888-476-5265) from 8:00am to 4:30pm, Pacific Time, Monday through Friday.


Rokenbok Toy Company

215 S. Highway 101, Suite 101
Solana Beach, CA 92075 (USA) Phone (858) 259-4433
1-888-4ROKBOK (1-888-476-5265)
e-mail: customerservice@rokenbok.com

www.rokenbok.com

Motorized Conveyor

Batteries are to be inserted with correct polarity. Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc) or nickel cadmium batteries. Remove the batteries during long periods of non-use. Never leave worn-out batteries in your conveyor. Battery leakage and corrosions can damage product. Do not attempt to re-charge non-rechargeable batteries.



©2007 Rokenbok Toy Company.
All rights reserved. ROKENBOK® is a registered
trademark of the Rokenbok Toy Company.

P/N#: 50-00733