






SD_CARD




FLASH










USB&USART




POWER




F1C200S




1.3TFT




MUSIC




PIN



MPU6050



LED&BOOT



WIFI

