

The Landord FX Whiskey Chaser is a vicious sounding high gain distortion with enough kick to cut through the worst of musical hangovers. Dial in the midrange with the tone knob and be very careful with the Gain control: adjust to taste!

### Operating Instructions



1. TRUE BYPASS FOOTSWITCH: Press the true bypass footswitch to begin drinking.
2. LED INDICATOR: Lights up underneath control knobs when effect is enabled
3. DIST: Increases the level of pain and saturation (begin with knob set well before noon: Landlord's orders!)
4. TONE: Increase the midrange beef and presence. This alters the entire tone and flavour of the gain.
5. LEVEL: Adjust the level of roar from the pedal
6. INPUT: Place your instrument cable here.
7. OUTPUT: Send the pain to your amp.
8. POWER ADAPTER INPUT: Use a centre negative 9V DC adapter to juice this pedal.
9. MODE SWITCH:
  - HOOCH - Natural distortion tone, like an overdriven vintage tube amp.
  - BOURBON - More modern, high-gain distortion, with tight low end and beefy mids.
  - SCOTCH - Classic well-defined, vintage-sounding high-gain distortion.

### Specifications

- Input Impedance: 1M Ohms
- Output Impedance: 470 Ohm
- Working Current: 25mA
- Power Supply: DC 9V (Plug polarity is positive on the barrel and negative in the centre)  $\oplus \ominus$
- Dimensions: 95mm(D)\*45mm(W)\*48mm(H)
- Weight: 240g (with box)