


Happy Hour is the best time of the day: relive it over and over with endless loops from Landlord FX's Happy Hour. Have fun bringing new creativity to your playing with unlimited overdubs and 10 minutes' worth of recording time, all in a simple and convenient design. With Landlord FX, it's always Happy Hour!

## Operating Instructions



- 1. FOOTSWITCH:** Use this to begin Happy Hour! This switch has multiple functions, please see 'How to Use' below.
- 2. LED INDICATOR:** Assess the status of your loops with this handy multi-function LED light. Please refer to 'How to Use' below.
- 3. LEVEL:** This determines how loud your loops are in relation to your dry guitar signal.
- 4. INPUT JACK:** Connect your guitar here.
- 5. OUTPUT JACK:** Deliver your Happy Hour Experience to your amp here.
- 6. POWER ADAPTER INPUT:** Happy Hour needs power! Connect a standard 9V, centre negative power adapter and it's beer o'clock!
- 7. USB INTERFACE:** Import/export WAV files and system updates.

## How to use

### How to record/overdubbing -

- Press the footswitch once when the LED is off, the Red light is on, indicating it is in the Recording mode
- Press the footswitch once in the Recording mode, the Green light is on, indicating it is in the Playback mode
- Press the footswitch once in the Playback mode, the Red light is on, indicating it is at the Overdubbing mode.
- Press the footswitch once in the Overdubbing mode, the Green light is on, indicating it is in the Playback mode.

### How to delete recording

- In the Playback/Overdubbing mode, press the footswitch and hold on for at least 2 seconds, the LED will blink twice rapidly, then the last recording is deleted.

### How to restore the recording -

- If you want to restore the last recording you have deleted in last step, press the footswitch and hold on for at least 2 seconds, the LED will blink twice rapidly, then the last recording is restored.

### How to stop/start/delete the loops

- In the Playback/Overdubbing mode, press the footswitch twice quickly, the LED will be blinking in Green, the Playback/Overdubbing is stopped
- Press the footswitch once when the playback is stopped, the Green light is on, the Playback starts again
- Press the footswitch and hold on for 2 seconds when the playback is stopped, the light is off, then all recordings are deleted.

## Specifications

- Maximum Recording Time: 10 Minutes
- Maximum Overdubbing Times: Unlimited
- Input: 1/4" Monaural Jack (Impedance: 470K Ohms)
- Output: 1/4" Monaural Jack (Impedance: 100 Ohms)
- Power Supply: DC 9V (Plug polarity is Positive on the barrel and negative in the centre ) 🔌 ⚡
- Working Current: 94 mA
- Size: 95(L)\*41.5(W)\*58(H)mm
- G.W: 290g
- Accessories: 1. Manual 2. USB cable (uploading and downloading with the computer, (Please download the software from our website at <http://www.landlordfx.com>)
- Note: Only WAV audio file can be uploaded to the looper from the computer