



How to install a CarpenPi



CarpenPi


Download the image

- Get it from <https://tinyurl.com/carpenpi-image>




Unzip the download

- Unzip the file you just downloaded (CarpenPi-raspberrypi-2021-10-06.zip)




Choose where to save the files

- Select “Show extracted files when complete”
- Extracting the zip file may take a few minutes




Download the Raspberry Pi Imager

- From <https://raspberrypi.org/software>




Start the Raspberry Pi Imager

- Run the program you just downloaded
- You will need administrator privileges on your computer.




Choose the file to write to the SD card

- Click “Choose OS”, then “Use custom”
- Find the file you just extracted from the zip.
 - It should be called carpenpi-2021-10-6.img or carpenpi-2021-10-6




Choose the Device to Write to

- Insert a blank SD card into your computer's SD card slot
 - Or use a USB SD card reader
- Click “Choose Storage”
- Choose your SD card device




Agree to the warning

- Remember:
Everything on your
SD card will be
deleted.




Wait for the SD Card to Write

- This will take several minutes




SD card finished

- You can now remove the SD card



Put the SD card in the Raspberry Pi




Power on the Raspberry Pi



Connect to the Carpenpi network

- Find the carpenpi WiFi network and connect to it



Connect to the CarpenPi website

- Go to <http://carpenpi.org>

