


BEND

FRONT OF STAND
BEND DOWNWARDS



BEND

BACK OF STAND
(FEATHER SIDE OF DISPLAY)
BEND UPWARDS

Cedar Grove Maker Studios

Sheet:

File: PCB_WeatherDisplay_Stand_2-4.kicad_pcb

Title: PCB_WeatherDisplay_Stand_2-4

Size: USLetter Date: 2025-01-21

KiCad E.D.A. 8.0.7

Rev: v0.0

Id: 1/1