











EXPLODED DIAGRAM REF STATIC	FIXTURE	PART NUMBER	DESCRIPTION	URL STATIC
1	ROGUEOUTCAST1LBEAM/08011930	PTF1100000464	connector J5F2C-W-B-LY (BOM#1)	https://chauvetvip.com/products/PTF1100000464_5-pin-XLR-IP-connector(M)-with-cover-(BOM#20)
2	ROGUEOUTCAST1LBEAM/08011930	PTF1100000465	connector K5F2C-W-B-LY (BOM#2)	https://chauvetvip.com/products/PTF1100000465_5-pin-XLR-IP-connector-(F)-with-cover
3	ROGUEOUTCAST1LBEAM/08011930	PTH070200011814	glave VV-P465-00-KS1 (BOM#3)	
4	ROGUEOUTCAST1LBEAM/08011930	PTH210200013526	fuse holder FH15-22A (防水) (BOM#4)	
5	ROGUEOUTCAST1LBEAM/08011930	PTH021000010966	fuse F5A (BOM#5)	
6	ROGUEOUTCAST1LBEAM/08011930	PTH070200000012	fuse cap IP-2W-C18 (BOM#6)	
7	ROGUEOUTCAST1LBEAM/08011930	PTF1100000469	connector SAC3MPX-LY Assembly (BOM#7)	https://chauvetvip.com/products/PTF1100000469_IP-power-in-connector-with-cover
8	ROGUEOUTCAST1LBEAM/08011930	PTF1100000468	connector SAC3FPX-LY Assembly(BOM#8)	https://chauvetvip.com/products/PTF1100000468_IP-power-out-connector-with-cover
9	ROGUEOUTCAST1LBEAM/08011930	PTH080500000017	rubber cover CNAC-FPX-LY (BOM#9)	
10	ROGUEOUTCAST1LBEAM/08011930	PTH080500000016	rubber cover CNAC-MPX-LY (BOM#10)	
11	ROGUEOUTCAST1LBEAM/08011930	PTH080500000027	USB C connector SCCMCDF-01 (BOM#11)	
12	ROGUEOUTCAST1LBEAM/08011930	PTH010102012834	USB press board IP-1W-A01-05 (BOM#12)	
13	ROGUEOUTCAST1LBEAM/08011930	PTH010101012314	pan lock mat board ROIP-140-A01-02 (BOM#13)	
14	ROGUEOUTCAST1LBEAM/08011930	PTH010101012113	pan lock block ROIP-140-A01-01 (BOM#14)	
15	ROGUEOUTCAST1LBEAM/08011930	PTH010203004342	handle screw IP-1W-B09 (BOM#15)	
16	ROGUEOUTCAST1LBEAM/08011930	PTH070100004421	handle IP-1W-C02 (BOM#16)	
17	ROGUEOUTCAST1LBEAM/08011930	PTH010201010196	base face cover IP-1W-B01 (BOM#17)	
18	ROGUEOUTCAST1LBEAM/08011930	PTH030100003792	display PCB ROIP-140 LED BEAM (BOM#18)	
19	ROGUEOUTCAST1LBEAM/08011930	PTH010101011195	display press board IP-1W-A01-02 (BOM#19)	https://chauvetvip.com/products/PTH010101011195_display-press-board-IP-1W-A01-02
20	ROGUEOUTCAST1LBEAM/08011930	PTH070200011643	display gasket SW-3WBAR-C08 (BOM#20)	
21	ROGUEOUTCAST1LBEAM/08011930	PTH070100004389	display cover board TOUGH-800BAR-C11 (BOM#21)	
22	ROGUEOUTCAST1LBEAM/08011930	PTH040301010902	PSU HL01-LP400S+36 (BOM#22)	
23	ROGUEOUTCAST1LBEAM/08011930	PTH010203004356	screw mat cover IP-1W-B10 (BOM#23)	
24	ROGUEOUTCAST1LBEAM/08011930	PTH010102011928	fan bracket IP-1W-A01-03 (BOM#24)	
25	ROGUEOUTCAST1LBEAM/08011930	PTH210200013385	fan ROIP-140 LED BEAM (BOM#25)	
26	ROGUEOUTCAST1LBEAM/08011930	PTH010504000184	waterproof cover IP-1W-B12 (BOM#26)	
27	ROGUEOUTCAST1LBEAM/08011930	PTH070200011846	gasket IP-1W-C09 (BOM#27)	
28	ROGUEOUTCAST1LBEAM/08011930	PTH120500000017	nut M22 (BOM#28)	
29	ROGUEOUTCAST1LBEAM/08011930	PTH070200011845	base gasket IP-1W-C06 (BOM#29)	
30	ROGUEOUTCAST1LBEAM/08011930	PTH010102014505	base board IP-1W-A01-01 (BOM#30)	
31	ROGUEOUTCAST1LBEAM/08011930	PTH070200000040	machine foot φ15*8 (BOM#31)	
32	ROGUEOUTCAST1LBEAM/08011930	PTH010504000162	arm cover ROIP-140-D02 (BOM#32)	
33	ROGUEOUTCAST1LBEAM/08011930	PTH070200011851	arm gasket ROIP-140-C03 (BOM#33)	
34	ROGUEOUTCAST1LBEAM/08011930	PTH010101012306	tilt bushing TOUGH-350B-A02-05 (BOM#34)	
35	ROGUEOUTCAST1LBEAM/08011930	PTH010102013844	tilt positioning chip ROIP-140-A02-10 (BOM#35)	
36	ROGUEOUTCAST1LBEAM/08011930	PTH110100000010	bearing 6906ZZ (BOM#36)	
37	ROGUEOUTCAST1LBEAM/08011930	PTH070200011822	yoke oilseal TC 35*45*5 (BOM#37)	
38	ROGUEOUTCAST1LBEAM/08011930	PTH010203005319	gear DL-378-06 (BOM#38)	
39	ROGUEOUTCAST1LBEAM/08011930	PTH090200004167	belt 3M-564-10mm (BOM#39)	
40	ROGUEOUTCAST1LBEAM/08011930	PTH010203005557	tilt bushing TOUGH-350B-BZ06 (BOM#40)	
41	ROGUEOUTCAST1LBEAM/08011930	PTH010504000163	arm bracket ROIP-140-D01 (BOM#41)	
42	ROGUEOUTCAST1LBEAM/08011930	PTH010203005552	tilt axis TOUGH-350B-BZ08 (BOM#42)	
43	ROGUEOUTCAST1LBEAM/08011930	PTH010203004541	screw press board TOUGH-300S-B20 (BOM#43)	
44	ROGUEOUTCAST1LBEAM/08011930	PTH120105000006	screw M5*6 (BOM#44)	
45	ROGUEOUTCAST1LBEAM/08011930	PTH010102013836	mat chip ROIP-140-A02-06 (BOM#45)	
46	ROGUEOUTCAST1LBEAM/08011930	PTH030100000099	magnetic sensor HE-10 (BOM#46)	
47	ROGUEOUTCAST1LBEAM/08011930	PTH010102013845	tilt touching board ROIP-140-A02-11 (BOM#47)	
48	ROGUEOUTCAST1LBEAM/08011930	PTH010102013843	tilt motor bracket ROIP-140-A02-09 (BOM#48)	
49	ROGUEOUTCAST1LBEAM/08011930	PTH030100000089	optocoupler PCB GD005 (BOM#49)	https://chauvetvip.com/products/PTH030100000089_optocoupler-PCB-GD005-E
50	ROGUEOUTCAST1LBEAM/08011930	PTH010203005315	optocoupler bracket ROIP-140-B01 (BOM#50)	
51	ROGUEOUTCAST1LBEAM/08011930	PTH210200013597	tilt belt pressing wheel ROIP-140 LED BEAM (BOM#51)	
52	ROGUEOUTCAST1LBEAM/08011930	PTH010101012353	tilt wiring board ROIP-140-A02-14 (BOM#52)	
53	ROGUEOUTCAST1LBEAM/08011930	PTH210200000942	tilt driving wheel DL-314-01-02/TOUGH 950W/TOUGH 300H/TOUGH 500 B (BOM#53)	
54	ROGUEOUTCAST1LBEAM/08011930	PTH210200013388	tilt motor ROIP-140 LED BEAM (BOM#54)	
55	ROGUEOUTCAST1LBEAM/08011930	PTH010101012070	tilt lock pick ROIP-140-A02-04 (BOM#55)	
56	ROGUEOUTCAST1LBEAM/08011930	PTH010203004547	lock pick fixing piece TOUGH-300S-B21 (BOM#56)	
57	ROGUEOUTCAST1LBEAM/08011930	PTH010102012233	shrapnel TOUGH-300S-A02-07 (BOM#57)	
58	ROGUEOUTCAST1LBEAM/08011930	PTH010203004552	pan magnetic sensor post TOUGH-300S-B11 (BOM#58)	
59	ROGUEOUTCAST1LBEAM/08011930	PTH010101012072	tilt lock fixing board ROIP-140-A02-07 (BOM#59)	
60	ROGUEOUTCAST1LBEAM/08011930	PTH070200000067	PVC cover 14*8 (BOM#60)	
61	ROGUEOUTCAST1LBEAM/08011930	PTH010101012137	pan magnetic sensor bracket 6906ZZ (BOM#61)	
62	ROGUEOUTCAST1LBEAM/08011930	PTH030100000124	magnetic sensor HE-24 (BOM#62)	
63	ROGUEOUTCAST1LBEAM/08011930	PTH010102013837	arm cover board ROIP-140-A02-03 (BOM#63)	
64	ROGUEOUTCAST1LBEAM/08011930	PTH070200011850	gasket ROIP-140-C02 (BOM#64)	
65	ROGUEOUTCAST1LBEAM/08011930	PTH010101012154	pan bracket TOUGH-350B-A02-01 (BOM#65)	
66	ROGUEOUTCAST1LBEAM/08011930	PTH010203005318	pan axis ROIP-140-BZ01 (BOM#66)	
67	ROGUEOUTCAST1LBEAM/08011930	PTH010102001275	pan mat chip EX-575-A01-20 (BOM#67)	
68	ROGUEOUTCAST1LBEAM/08011930	PTH010102014006	pan positioning chip TOUGH-350B-A02-02 (BOM#68)	
69	ROGUEOUTCAST1LBEAM/08011930	PTH010203005320	gear DL-384-09 (BOM#69)	
70	ROGUEOUTCAST1LBEAM/08011930	PTH070200011823	yoke oilseal TC 65*75*8 (BOM#70)	
71	ROGUEOUTCAST1LBEAM/08011930	PTH010203005322	gasket ROIP-140-B04 (BOM#71)	
72	ROGUEOUTCAST1LBEAM/08011930	PTH110100004364	bearing 6812ZZ (BOM#72)	
73	ROGUEOUTCAST1LBEAM/08011930	PTH010102014359	arm bracket bearing press board TOUGH-350B-A02-03 (BOM#73)	
74	ROGUEOUTCAST1LBEAM/08011930	PTH010201010441	arm bracket bushing TOUGH-350B-BZ05 (BOM#74)	
75	ROGUEOUTCAST1LBEAM/08011930	PTH010101012309	pan bearing press board TOUGH-350B-A02-04 (BOM#75)	
76	ROGUEOUTCAST1LBEAM/08011930	PTH010203005715	pan bushing ROIP-140-BZ02 (BOM#76)	
77	ROGUEOUTCAST1LBEAM/08011930	PTH090200004244	belt 3M-381-10mm (BOM#77)	
78	ROGUEOUTCAST1LBEAM/08011930	PTH110100004338	bearing 6806ZZ (BOM#78)	
79	ROGUEOUTCAST1LBEAM/08011930	PTH010203004353	bearing mat cover IP-1W-BZ07 (BOM#79)	
80	ROGUEOUTCAST1LBEAM/08011930	PTH110100000010	bearing 6906ZZ (BOM#80)	

81	ROGUEOUTCAST1LBEAM/08011930	PTH010203000104	copper nut EX-575-B03 (BOM#81)	
82	ROGUEOUTCAST1LBEAM/08011930	PTH010301000021	standoff φ5*50 (BOM#82)	
83	ROGUEOUTCAST1LBEAM/08011930	PTH010203004357	pan support bracket IP-1W-B05 (BOM#83)	
84	ROGUEOUTCAST1LBEAM/08011930	PTH010102013840	pan lock pick ROIP-140-A02-05 (BOM#84)	
85	ROGUEOUTCAST1LBEAM/08011930	PTH010102013842	motor bracket accessory board ROIP-140-A02-08 (BOM#85)	
86	ROGUEOUTCAST1LBEAM/08011930	PTH010203005315	optocoupler bracket ROIP-140-B01 (BOM#86)	
87	ROGUEOUTCAST1LBEAM/08011930	PTH030100000089	optocoupler PCB GD005 (BOM#87)	https://chauvetvip.com/products/PTH030100000089_optocoupler-PCB-GD005-E
88	ROGUEOUTCAST1LBEAM/08011930	PTH010102012235	pan optocoupler mat board TOUGH-300S-A02-09 (BOM#88)	
89	ROGUEOUTCAST1LBEAM/08011930	PTH010101012066	pan motor bracket ROIP-140-A02-01 (BOM#89)	
90	ROGUEOUTCAST1LBEAM/08011930	PTH030100003782	pan/tilt PCB MH319 (BOM#90)	
91	ROGUEOUTCAST1LBEAM/08011930	PTH010101012307	tilt wiring bracket TOUGH-350B-A02-06 (BOM#91)	
92	ROGUEOUTCAST1LBEAM/08011930	PTH010102011929	desiccant press board IP-1W-A01-04 (BOM#92)	
93	ROGUEOUTCAST1LBEAM/08011930	PTH150600000008	fan cover 9*9 (BOM#93)	
94	ROGUEOUTCAST1LBEAM/08011930	PTH210200013390	fan ROIP-140 LED BEAM (BOM#94)	
95	ROGUEOUTCAST1LBEAM/08011930	PTH010102014637	safety cable hook LS-440-A03-29-A (BOM#95)	
96	ROGUEOUTCAST1LBEAM/08011930	PTH010102013851	fan bracket ROIP-140-A03-06 (BOM#96)	
97	ROGUEOUTCAST1LBEAM/08011930	PTH070100004500	wiring cover IP-1W-C12 (BOM#97)	
98	ROGUEOUTCAST1LBEAM/08011930	PTH010101012268	LED module positioning board ROIP-140-A03-15 (BOM#98)	
99	ROGUEOUTCAST1LBEAM/08011930	PTH010501004180	heat sink CD-Z50 (BOM#99)	
100	ROGUEOUTCAST1LBEAM/08011930	PTH030100006010	LED driver PCB LJB059 (BOM#100)	
101	ROGUEOUTCAST1LBEAM/08011930	PTH060400000030	LED module SUL90-80-R00-015 (BOM#101)	
102	ROGUEOUTCAST1LBEAM/08011930	PTH010101012080	fan bracket 2 ROIP-140-A03-11 (BOM#102)	
103	ROGUEOUTCAST1LBEAM/08011930	PTH210200013389	fan ROIP-140 LED BEAM (BOM#103)	
104	ROGUEOUTCAST1LBEAM/08011930	PTH210200013293	color wheel ROIP-140 LED BEAM (BOM#104)	
106	ROGUEOUTCAST1LBEAM/08011930	PTH010203004401	gear DL-312-10 (BOM#106)	
107	ROGUEOUTCAST1LBEAM/08011930	PTH090200004238	belt 3M-216-3mm (BOM#107)	
108	ROGUEOUTCAST1LBEAM/08011930	PTH210200013400	rotating gobo wheel ROIP-140 LED BEAM (BOM#108)	
109	ROGUEOUTCAST1LBEAM/08011930	PTH030100000098	magnetic sensor HE-10 (BOM#109)	
110	ROGUEOUTCAST1LBEAM/08011930	PTH010302000134	standoff 3*11 (BOM#110)	
111	ROGUEOUTCAST1LBEAM/08011930	PTH010102012882	screw mat board MK0XS-A03-12 (BOM#111)	
112	ROGUEOUTCAST1LBEAM/08011930	PTH010102013856	wiring bracket ROIP-140-A03-07 (BOM#112)	
113	ROGUEOUTCAST1LBEAM/08011930	PTH030100004108	motor PCB MH259 (BOM#113)	
114	ROGUEOUTCAST1LBEAM/08011930	PTH010101012073	gobo motor bracket ROIP-140-A03-01 (BOM#114)	
115	ROGUEOUTCAST1LBEAM/08011930	PTH010102013855	gobo bracket strenghen board ROIP-140-A03-12 (BOM#115)	
116	ROGUEOUTCAST1LBEAM/08011930	PTH010101012219	motor light barrier ROIP-140-A03-13 (BOM#116)	
117	ROGUEOUTCAST1LBEAM/08011930	PTH040100000038	motor 16HY018-15H (BOM#117)	
118	ROGUEOUTCAST1LBEAM/08011930	PTH040100000084	motor 39SHD0611-20YH (BOM#118)	
119	ROGUEOUTCAST1LBEAM/08011930	PTH010203005201	module fixing 1 MIP-500-B11 (BOM#119)	
120	ROGUEOUTCAST1LBEAM/08011930	PTH010203005200	module fixing 2 MIP-500-B12 (BOM#120)	
121	ROGUEOUTCAST1LBEAM/08011930	PTH030100004006	driver PCB MH326 (BOM#121)	
122	ROGUEOUTCAST1LBEAM/08011930	PTH210200013344	frost ROIP-140 LED BEAM (BOM#122)	
123	ROGUEOUTCAST1LBEAM/08011930	PTH010302000018	standoff H6*21.5 (BOM#123)	
124	ROGUEOUTCAST1LBEAM/08011930	PTH010102014081	motor instal board ROIP-140-A03-14 (BOM#124)	
125	ROGUEOUTCAST1LBEAM/08011930	PTH010302000137	standoff 3*7 (BOM#125)	
126	ROGUEOUTCAST1LBEAM/08011930	PTH010301000015	standoff φ5*16 (BOM#126)	
127	ROGUEOUTCAST1LBEAM/08011930	PTH040100000058	motor 14HY301-30H (BOM#127)	
128	ROGUEOUTCAST1LBEAM/08011930	PTH010101012074	prism motor bracket ROIP-140-A03-02 (BOM#128)	
129	ROGUEOUTCAST1LBEAM/08011930	PTH0010302003928	standoff H7*45 (BOM#129)	
130	ROGUEOUTCAST1LBEAM/08011930	PTH040100000082	motor 39SHD0611-15YH (BOM#130)	
131	ROGUEOUTCAST1LBEAM/08011930	PTH010302000054	standoff H6*17 (BOM#131)	
132	ROGUEOUTCAST1LBEAM/08011930	PTH010302000048	standoff H6*14 (BOM#132)	
133	ROGUEOUTCAST1LBEAM/08011930	PTH010302003808	standoff 3*29 (BOM#133)	
134	ROGUEOUTCAST1LBEAM/08011930	PTH010302000070	standoff H6*25 (BOM#134)	
135	ROGUEOUTCAST1LBEAM/08011930	PTH030100000101	magnetic sensor HE-11 (BOM#135)	
136	ROGUEOUTCAST1LBEAM/08011930	PTH090200000102	rubber belt 162-3M-3 (BOM#136)	
137	ROGUEOUTCAST1LBEAM/08011930	PTH030100000115	magnetic sensor HE-18 (BOM#137)	
138	ROGUEOUTCAST1LBEAM/08011930	PTH010203000317	gear DL-315-19 (BOM#138)	
139	ROGUEOUTCAST1LBEAM/08011930	PTH010101012420	light barrier ROIP-140-A03-08 (BOM#139)	
140	ROGUEOUTCAST1LBEAM/08011930	PTH010302000041	standoff H6*10 (BOM#140)	
141	ROGUEOUTCAST1LBEAM/08011930	PTH210200013342	8 facet prism ROIP-140 LED BEAM (BOM#141)	
142	ROGUEOUTCAST1LBEAM/08011930	PTH210104010920	linear prism ROIP-140 LED BEAM (BOM#142)	
143	ROGUEOUTCAST1LBEAM/08011930	PTH090200000009	belt 3M-228-3mm (BOM#143)	
144	ROGUEOUTCAST1LBEAM/08011930	PTH010101012079	prism motor bracket 2 ROIP-140-A03-09 (BOM#144)	
145	ROGUEOUTCAST1LBEAM/08011930	PTH010102013849	light barrier ROIP-140-A03-04 (BOM#145)	
146	ROGUEOUTCAST1LBEAM/08011930	PTH040100000125	motor 39SHD0617-50NY (BOM#146)	
147	ROGUEOUTCAST1LBEAM/08011930	PTH010101012075	focus motor bracket ROIP-140-A03-03 (BOM#147)	
148	ROGUEOUTCAST1LBEAM/08011930	PTH010302000041	standoff H6*10 (BOM#148)	
149	ROGUEOUTCAST1LBEAM/08011930	PTH010101012255	motor strenghen board ROIP-140-A03-17 (BOM#149)	
150	ROGUEOUTCAST1LBEAM/08011930	PTH010302000093	standoff H6*8 (BOM#150)	
151	ROGUEOUTCAST1LBEAM/08011930	PTH0010302003914	standoff H7*50.5 (BOM#151)	
152	ROGUEOUTCAST1LBEAM/08011930	PTH010203000076	slide cover DJ-3R-B01 (BOM#152)	
153	ROGUEOUTCAST1LBEAM/08011930	PTH010203005317	slider ROIP-140-B03 (BOM#153)	
154	ROGUEOUTCAST1LBEAM/08011930	PTH010101012077	lens bracket ROIP-140-A03-05 (BOM#154)	
155	ROGUEOUTCAST1LBEAM/08011930	PTH050101004290	focus set A152-161 (BOM#155)	
156	ROGUEOUTCAST1LBEAM/08011930	PTH010101012256	focus front bracket ROIP-140-A03-16 (BOM#156)	
157	ROGUEOUTCAST1LBEAM/08011930	PTH010504000159	lens bracket ROIP-140-D05 (BOM#157)	
158	ROGUEOUTCAST1LBEAM/08011930	PTH070200011853	lens gasket ROIP-140-C05 (BOM#158)	
159	ROGUEOUTCAST1LBEAM/08011930	PTH050101004291	objective lens A152-161 (BOM#159)	
160	ROGUEOUTCAST1LBEAM/08011930	PTH010101012081	lens bracket ROIP-140-A03-10 (BOM#160)	
161	ROGUEOUTCAST1LBEAM/08011930	PTH070100004612	lens cover ROIP-140-C01 (BOM#161)	
162	ROGUEOUTCAST1LBEAM/08011930	PTH070200011852	head cover gasket ROIP-140-C04 (BOM#162)	
163	ROGUEOUTCAST1LBEAM/08011930	PTH010504000160	head cover ROIP-140-D04 (BOM#163)	
164	ROGUEOUTCAST1LBEAM/08011930	PTH010504000161	head side cover ROIP-140-D03 (BOM#164)	
165	ROGUEOUTCAST1LBEAM/08011930	PTH010101012084	tilt lock block ROIP-140-A02-12 (BOM#165)	
166	ROGUEOUTCAST1LBEAM/08011930	PTH210200012077	120mm Omega Bracket (BOM#166)	https://chauvetvip.com/products/PTH210200012077_Omega-Bracket