





B







EXPLODED DIAGRAM REF STATIC	FIXTURE	PART NUMBER	DESCRIPTION	URL STATIC
1	ROGUEOUTCAST2BEAM/08011973	PTH010101011365	pan lock block TOUGH-300S-A01-03 (BOM#1)	
2	ROGUEOUTCAST2BEAM/08011973	PTH010504000246	base face cover ROIP-400H-D03 (BOM#2)	
3	ROGUEOUTCAST2BEAM/08011973	PTH010102012834	USB press board IP-1W-A01-05 (BOM#3)	
4	ROGUEOUTCAST2BEAM/08011973	PTH080500000027	USB-C connector SCCMCDF-01 (BOM#4)	
5	ROGUEOUTCAST2BEAM/08011973	PTH070200011814	valve VV-P465-00-KS1 (BOM#5)	
6	ROGUEOUTCAST2BEAM/08011973	PTF1100000465	connector K5F2C-W-B-LY (BOM#6)	https://chauvetvip.com/products/PTF1100000465_5-pin-XLR-IP-connector-(F)-with-cover
7	ROGUEOUTCAST2BEAM/08011973	PTF1100000464	connector J5F2C-W-B-LY (BOM#7)	https://chauvetvip.com/products/PTF1100000464_5-pin-XLR-IP-connector(M)-with-cover-(BOM#20)
8	ROGUEOUTCAST2BEAM/08011973	PTH070200000012	fuse cap IP-2W-C18 (BOM#8)	
9	ROGUEOUTCAST2BEAM/08011973	PTH021000000022	fuse F8A (BOM#9)	
10	ROGUEOUTCAST2BEAM/08011973	PTH210200013526	fuse holder FH15-22A (BOM#10)	
11	ROGUEOUTCAST2BEAM/08011973	PTF1100000469	connector SAC3MPX-LY Assembly (BOM#11)	https://chauvetvip.com/products/PTF1100000469_IP-power-in-connector-with-cover
12	ROGUEOUTCAST2BEAM/08011973	PTH080500000016	rubber cover CNAC-MPX-LY (BOM#12)	
13	ROGUEOUTCAST2BEAM/08011973	PTH010101012529	output connector barrier ROIP-400H-A01-01 (BOM#13)	
14	ROGUEOUTCAST2BEAM/08011973	PTH030100003881	display PCB ROIP-300 BEAM (BOM#14)	
15	ROGUEOUTCAST2BEAM/08011973	PTH010101011195	display press board IP-1W-A01-02 (BOM#15)	https://chauvetvip.com/products/PTH010101011195_display-press-board-IP-1W-A01-02
16	ROGUEOUTCAST2BEAM/08011973	PTH070100004389	display cover board TOUGH-800BAR-C11 (BOM#16)	
17	ROGUEOUTCAST2BEAM/08011973	PTH070200011643	display gasket SW-3WBAR-C08 (BOM#17)	
18	ROGUEOUTCAST2BEAM/08011973	PTH010102014008	ballest fixing board TOUGH-350B-A01-01 (BOM#18)	
19	ROGUEOUTCAST2BEAM/08011973	PTH010102012539	PSU press board MIP-1950W-A01-06 (BOM#19)	
20	ROGUEOUTCAST2BEAM/08011973	PTH010102012573	PSU press board 2 MIP-1950W-A01-07 (BOM#20)	
21	ROGUEOUTCAST2BEAM/08011973	PTH040302004178	ballast PHG251A4 (BOM#21)	
22	ROGUEOUTCAST2BEAM/08011973	PTH040301010907	PSU H30-PU550D+32 (BOM#22)	
23	ROGUEOUTCAST2BEAM/08011973	PTH210200013361	fan ROIP-400 HYBRID/ROIP-400 BEAM (BOM#23)	
24	ROGUEOUTCAST2BEAM/08011973	PTH010102012068	dessicant press board TOUGH-300S-A01-02 (BOM#24)	
25	ROGUEOUTCAST2BEAM/08011973	PTH010102013064	dessicant cover board TOUGH-300S-A01-07 (BOM#25)	
26	ROGUEOUTCAST2BEAM/08011973	PTH010504000184	waterproof cover IP-1W-B12 (BOM#26)	
27	ROGUEOUTCAST2BEAM/08011973	PTH120500000017	nut M22 (BOM#27)	
28	ROGUEOUTCAST2BEAM/08011973	PTH070200011846	waterproof cover gasket IP-1W-C09 (BOM#28)	
29	ROGUEOUTCAST2BEAM/08011973	PTH070200011861	base gasket TOUGH-300S-C02 (BOM#29)	
30	ROGUEOUTCAST2BEAM/08011973	PTH010102015487	base board TOUGH-300S-A01-01 (BOM#30)	
31	ROGUEOUTCAST2BEAM/08011973	PTH070200000054	machine foot CD-JD30-21 (BOM#31)	
34	ROGUEOUTCAST2BEAM/08011973	PTH010203005552	tilt axis 1 TOUGH-350B-BZ08 (BOM#34)	
35	ROGUEOUTCAST2BEAM/08011973	PTH010504000163	arm bracket ROIP-140-D01 (BOM#35)	
36	ROGUEOUTCAST2BEAM/08011973	PTH210200013734	tilt bushing ROIP-300 BEAM/TOUGH 350 BEAM (BOM#36)	
37	ROGUEOUTCAST2BEAM/08011973	PTH010101012306	tilt bushing cover board TOUGH-350B-A02-05 (BOM#37)	
38	ROGUEOUTCAST2BEAM/08011973	PTH010203005319	gear DL-378-06 (BOM#38)	
39	ROGUEOUTCAST2BEAM/08011973	PTH010102013844	tilt positioning chip ROIP-140-A02-10 (BOM#39)	
40	ROGUEOUTCAST2BEAM/08011973	PTH090200004167	belt 3M-564-10mm (BOM#40)	
41	ROGUEOUTCAST2BEAM/08011973	PTH010102013845	tilt stopper board ROIP-140-A02-11 (BOM#41)	
42	ROGUEOUTCAST2BEAM/08011973	PTH030100000099	magnetic sensor HE-10 (BOM#42)	
43	ROGUEOUTCAST2BEAM/08011973	PTH070200011851	arm gasket ROIP-140-C03 (BOM#43)	
44	ROGUEOUTCAST2BEAM/08011973	PTH010504000162	arm cover ROIP-140-D02 (BOM#44)	
45	ROGUEOUTCAST2BEAM/08011973	PTH210200000942	tilt driving wheel DL-314-01-02/TOUGH 950W/TOUGH 300H/TOUGH 500 B (BOM#45)	
46	ROGUEOUTCAST2BEAM/08011973	PTH030100000089	optocoupler PCB GD005 (BOM#46)	https://chauvetvip.com/products/PTH030100000089_optocoupler-PCB-GD005-E
47	ROGUEOUTCAST2BEAM/08011973	PTH010203005315	optocoupler bracket ROIP-140-B01 (BOM#47)	
48	ROGUEOUTCAST2BEAM/08011973	PTH010102013843	tilt motor bracket ROIP-140-A02-09 (BOM#48)	
49	ROGUEOUTCAST2BEAM/08011973	PTH210200013388	tilt motor ROIP-140 LED BEAM (BOM#49)	
50	ROGUEOUTCAST2BEAM/08011973	PTH010203004541	screw press board TOUGH-300S-B20 (BOM#50)	
51	ROGUEOUTCAST2BEAM/08011973	PTH120105000006	screw M5*6 (BOM#51)	
52	ROGUEOUTCAST2BEAM/08011973	PTH210200013755	tilt belt pressing wheel ROIP-300 BEAM (BOM#52)	
53	ROGUEOUTCAST2BEAM/08011973	PTH010101012353	tilt wiring board ROIP-140-A02-14 (BOM#53)	
54	ROGUEOUTCAST2BEAM/08011973	PTH010102012233	shrapnel TOUGH-300S-A02-07 (BOM#54)	
55	ROGUEOUTCAST2BEAM/08011973	PTH070200000067	PVC cover 14*8 (BOM#55)	
56	ROGUEOUTCAST2BEAM/08011973	PTH010101012465	pan lock pick TOUGH-350B-A02-07 (BOM#56)	
57	ROGUEOUTCAST2BEAM/08011973	PTH010203004547	pick fixing 2 TOUGH-300S-B21 (BOM#57)	
58	ROGUEOUTCAST2BEAM/08011973	PTH010203005408	pan axis TOUGH-350B-BZ04 (BOM#58)	
59	ROGUEOUTCAST2BEAM/08011973	PTH010102001275	pan mat chip EX-575-A01-20 (BOM#59)	
60	ROGUEOUTCAST2BEAM/08011973	PTH010102014006	pan positioning chip TOUGH-350B-A02-02 (BOM#60)	
61	ROGUEOUTCAST2BEAM/08011973	PTH010203004552	pan magnetic sensor post TOUGH-300S-B11 (BOM#61)	
62	ROGUEOUTCAST2BEAM/08011973	PTH010203005745	gear DL-384-10 (BOM#62)	
63	ROGUEOUTCAST2BEAM/08011973	PTH090200004244	belt 3M-381-10mm (BOM#63)	
64	ROGUEOUTCAST2BEAM/08011973	PTH210200013735	arm bracket bushing ROIP-300 BEAM/TOUGH 350 BEAM (BOM#64)	
65	ROGUEOUTCAST2BEAM/08011973	PTH110100004371	bearing 6906Z (BOM#65)	
66	ROGUEOUTCAST2BEAM/08011973	PTH010203005403	gasket TOUGH-350B-BZ03 (BOM#66)	
67	ROGUEOUTCAST2BEAM/08011973	PTH010203005409	bearing bushing TOUGH-350B-BZ02 (BOM#67)	
68	ROGUEOUTCAST2BEAM/08011973	PTH010203005410	pan bushing TOUGH-350B-BZ01 (BOM#68)	
69	ROGUEOUTCAST2BEAM/08011973	PTH110100004372	bearing 6206Z (BOM#69)	
70	ROGUEOUTCAST2BEAM/08011973	PTH010203005406	wiring ring TOUGH-350B-B01 (BOM#70)	
71	ROGUEOUTCAST2BEAM/08011973	PTH010203000104	copper nut EX-575-B03 (BOM#71)	
72	ROGUEOUTCAST2BEAM/08011973	PTH010504000266	pan support bracket TOUGH-300S-B22 (BOM#72)	
73	ROGUEOUTCAST2BEAM/08011973	PTH070200011767	silicone ring φ12*φ2 (BOM#73)	
74	ROGUEOUTCAST2BEAM/08011973	PTH010102012792	wire barrier MIP-1950W-A01-09 (BOM#74)	
75	ROGUEOUTCAST2BEAM/08011973	PTH010203004662	base wire cover MIP-1950W-B03 (BOM#75)	
76	ROGUEOUTCAST2BEAM/08011973	PTH010102012231	base fan bracket TOUGH-300S-A01-04 (BOM#76)	
77	ROGUEOUTCAST2BEAM/08011973	PTH010203005560	screw mat TOUGH-350B-B05 (BOM#77)	
78	ROGUEOUTCAST2BEAM/08011973	PTH010101012072	tilt lock fixing board ROIP-140-A02-07 (BOM#78)	
79	ROGUEOUTCAST2BEAM/08011973	PTH010101012070	tilt lock pick ROIP-140-A02-04 (BOM#79)	
80	ROGUEOUTCAST2BEAM/08011973	PTH2020302431221	magnetic sensor HE-24 (BOM#80)	https://chauvetvip.com/products/PTH2020302431221_magnetic-sensor-HE-24A
81	ROGUEOUTCAST2BEAM/08011973	PTH010101012154	pan bracket TOUGH-350B-A02-01 (BOM#81)	
82	ROGUEOUTCAST2BEAM/08011973	PTH010101012137	pan magnetic sensor bracket ROIP-140-A02-13 (BOM#82)	

83	ROGUEOUTCAST2BEAM/08011973	PTH070200011850	yoke gasket ROIP-140-C02 (BOM#83)	
84	ROGUEOUTCAST2BEAM/08011973	PTH010101012069	arm cover board ROIP-140-A02-03 (BOM#84)	
85	ROGUEOUTCAST2BEAM/08011973	PTH010203005553	tilt axis 2 TOUGH-350B-BZ07 (BOM#85)	
86	ROGUEOUTCAST2BEAM/08011973	PTH010101012307	tilt wiring bracket TOUGH-350B-A02-06 (BOM#86)	
87	ROGUEOUTCAST2BEAM/08011973	PTH010301000021	standoff φ5*50 (BOM#87)	
88	ROGUEOUTCAST2BEAM/08011973	PTH030100003782	pan/tilt PCB MH319 (BOM#88)	
89	ROGUEOUTCAST2BEAM/08011973	PTH210200013387	pan motor ROIP-140 LED BEAM (BOM#89)	
90	ROGUEOUTCAST2BEAM/08011973	PTH010101012066	pan motor bracket ROIP-140-A02-01 (BOM#90)	
91	ROGUEOUTCAST2BEAM/08011973	PTH010102013842	motor bracket accessory board ROIP-140-A02-08 (BOM#91)	
92	ROGUEOUTCAST2BEAM/08011973	PTH010102012235	pan optocoupler board TOUGH-300S-A02-09 (BOM#92)	
93	ROGUEOUTCAST2BEAM/08011973	PTH010102000387	optocoupler bracket T2X-BAR-B04 (BOM#93)	
94	ROGUEOUTCAST2BEAM/08011973	PTH010504000171	lamp back cover ROIP-300B-D03 (BOM#94)	
95	ROGUEOUTCAST2BEAM/08011973	PTH010101012359	lamp back cover fixing board TOUGH-350B-A03-26 (BOM#95)	
96	ROGUEOUTCAST2BEAM/08011973	PTH070100004638	back cover TOUGH-350B-C01 (BOM#96)	
97	ROGUEOUTCAST2BEAM/08011973	PTH070100004710	lamp cover gasket TOUGH-350B-C04 (BOM#97)	
98	ROGUEOUTCAST2BEAM/08011973	PTH010101012357	fan bracket TOUGH-350B-A03-24 (BOM#98)	
99	ROGUEOUTCAST2BEAM/08011973	PTH010101012162	fan bracket TOUGH-350B-A03-04 (BOM#99)	
100	ROGUEOUTCAST2BEAM/08011973	PTH210200013691	fan ROIP-300 BEAM (BOM#100)	
101	ROGUEOUTCAST2BEAM/08011973	PTH070100004500	wiring cover IP-1W-C12 (BOM#101)	
102	ROGUEOUTCAST2BEAM/08011973	PTH010101001610	safety cable hook LS-440-A03-29 (BOM#102)	
103	ROGUEOUTCAST2BEAM/08011973	PTH010501004184	heatsink CD-Z51 (BOM#103)	
104	ROGUEOUTCAST2BEAM/08011973	PTH070200011880	silicone tape 3*3*130 (BOM#104)	
105	ROGUEOUTCAST2BEAM/08011973	PTH010102013984	shrapnel TOUGH-350B-A03-03 (BOM#105)	
106	ROGUEOUTCAST2BEAM/08011973	PTH010102013985	shrapnel TOUGH-350B-A03-02 (BOM#106)	
107	ROGUEOUTCAST2BEAM/08011973	PTH010102014649	lamp top adjust bracket TOUGH-350B-A03-32 (BOM#107)	
108	ROGUEOUTCAST2BEAM/08011973	PTH060100000003	lamp NSL300 (BOM#108)	
109	ROGUEOUTCAST2BEAM/08011973	PTH010203005748	fan installation board TOUGH-350B-B06 (BOM#109)	
110	ROGUEOUTCAST2BEAM/08011973	PTH010102014927	lamp bottom adjust bracket TOUGH-350B-A03-31 (BOM#110)	
111	ROGUEOUTCAST2BEAM/08011973	PTH010102013995	fan blower base board TOUGH-350B-A03-14 (BOM#111)	
112	ROGUEOUTCAST2BEAM/08011973	PTH010203005769	blower TOUGH-350B-B07 (BOM#112)	
113	ROGUEOUTCAST2BEAM/08011973	PTH210200013687	fan ROIP-300 BEAM (BOM#113)	
114	ROGUEOUTCAST2BEAM/08011973	PTH010102013987	lamp support board TOUGH-350B-A03-01 (BOM#114)	
115	ROGUEOUTCAST2BEAM/08011973	PTH210104010934	heatsink TOUGH 350 BEAM (BOM#115)	
116	ROGUEOUTCAST2BEAM/08011973	PTH010203005411	standoff TOUGH-350B-B03 (BOM#116)	
117	ROGUEOUTCAST2BEAM/08011973	PTH120301000008	spring 12*30*1.0 (BOM#117)	
118	ROGUEOUTCAST2BEAM/08011973	PTH021102000014	temperature controller 140 (BOM#118)	
119	ROGUEOUTCAST2BEAM/08011973	PTH010101012354	fan switch board TOUGH-350B-A03-25 (BOM#119)	
120	ROGUEOUTCAST2BEAM/08011973	PTH030100004122	switch PCB ZJ069 (BOM#120)	
121	ROGUEOUTCAST2BEAM/08011973	PTH080100000076	connector GHR1.25-5Y (BOM#121)	
122	ROGUEOUTCAST2BEAM/08011973	PTH010102014644	connector installation board TOUGH-350B-A03-23 (BOM#122)	
123	ROGUEOUTCAST2BEAM/08011973	PTH010102013990	lamp wind board TOUGH-350B-A03-08 (BOM#123)	
124	ROGUEOUTCAST2BEAM/08011973	PTH010102015391	fan heatsink TOUGH-350B-A03-30 (BOM#124)	
125	ROGUEOUTCAST2BEAM/08011973	PTH210200013420	shutter A TOUGH 350 BEAM (BOM#125)	
126	ROGUEOUTCAST2BEAM/08011973	PTH210200013622	shutter B TOUGH 350 BEAM (BOM#126)	
127	ROGUEOUTCAST2BEAM/08011973	PTH210200013427	color wheel TOUGH 350 BEAM (BOM#127)	
128	ROGUEOUTCAST2BEAM/08011973	PTH010301003770	standoff φ6*18 (BOM#128)	
129	ROGUEOUTCAST2BEAM/08011973	PTH210200013525	static gobo wheel TOUGH 350 BEAM (BOM#129)	
130	ROGUEOUTCAST2BEAM/08011973	PTH030100000098	magnetic sensor HE-10 (BOM#130)	
131	ROGUEOUTCAST2BEAM/08011973	PTH010102014001	color wheel magnetic sensor TOUGH-350B-A03-06 (BOM#131)	
132	ROGUEOUTCAST2BEAM/08011973	PTH010101012155	gobo motor bracket TOUGH-350B-A03-07 (BOM#132)	
133	ROGUEOUTCAST2BEAM/08011973	PTH210200013690	fan ROIP-300 BEAM (BOM#133)	
134	ROGUEOUTCAST2BEAM/08011973	PTH010101012160	fan TOUGH-350B-A03-13 (BOM#134)	
135	ROGUEOUTCAST2BEAM/08011973	PTH010102013997	wind guide board TOUGH-350B-A03-15 (BOM#135)	
136	ROGUEOUTCAST2BEAM/08011973	PTH010203005200	module fixing 2 MIP-500-B12 (BOM#136)	
137	ROGUEOUTCAST2BEAM/08011973	PTH010203005201	module fixing 1 MIP-500-B11 (BOM#137)	
138	ROGUEOUTCAST2BEAM/08011973	PTH030100004008	motor driver PCB MH326 (BOM#138)	
139	ROGUEOUTCAST2BEAM/08011973	PTH010101012328	gobo light blocker TOUGH-350B-A03-22 (BOM#139)	
140	ROGUEOUTCAST2BEAM/08011973	PTH040100003733	motor 39SHD2201G-13 (BOM#140)	
141	ROGUEOUTCAST2BEAM/08011973	PTH040100003729	motor 39SHD2201GZ-20 (BOM#141)	
142	ROGUEOUTCAST2BEAM/08011973	PTH040100003739	motor 39SHD2201GZ-35 (BOM#142)	
143	ROGUEOUTCAST2BEAM/08011973	PTH040100003683	motor 39SHD2201GZ-30 (BOM#143)	
144	ROGUEOUTCAST2BEAM/08011973	PTH210200013685	fan ROIP-300 BEAM (BOM#144)	
145	ROGUEOUTCAST2BEAM/08011973	PTH010102014059	fan mat board TOUGH-350B-A03-16 (BOM#145)	
146	ROGUEOUTCAST2BEAM/08011973	PTH030100003991	motor PCB MH340 (BOM#146)	
147	ROGUEOUTCAST2BEAM/08011973	PTH010101012326	prism motor bracket TOUGH-350B-A03-19 (BOM#147)	
148	ROGUEOUTCAST2BEAM/08011973	PTH010302003892	standoff H7*44 (BOM#148)	
149	ROGUEOUTCAST2BEAM/08011973	PTH010302000140	standoff 3*16 (BOM#149)	
150	ROGUEOUTCAST2BEAM/08011973	PTH010101012362	magnetic sensor bracket TOUGH-350B-A03-11 (BOM#150)	
151	ROGUEOUTCAST2BEAM/08011973	PTH2020302431221	magnetic sensor HE-24 (BOM#151)	https://chauvetvip.com/products/PTH2020302431221_magnetic-sensor-HE-24A
152	ROGUEOUTCAST2BEAM/08011973	PTH030100000117	magnetic sensor HE-18 (BOM#152)	
153	ROGUEOUTCAST2BEAM/08011973	PTH010302003804	standoff 3*25 (BOM#153)	
154	ROGUEOUTCAST2BEAM/08011973	PTH010101012601	belt light blocker TOUGH-350B-A03-29 (BOM#154)	
155	ROGUEOUTCAST2BEAM/08011973	PTH010101012619	fan light blocker TOUGH-350B-A03-09 (BOM#155)	
156	ROGUEOUTCAST2BEAM/08011973	PTH210200013591	frost TOUGH 350 BEAM (BOM#156)	
157	ROGUEOUTCAST2BEAM/08011973	PTH010203000317	gear DL-315-19 (BOM#157)	
158	ROGUEOUTCAST2BEAM/08011973	PTH090200004198	belt 3M-162-3mm (BOM#158)	
159	ROGUEOUTCAST2BEAM/08011973	PTH210200013681	8 facet prism ROIP-300 BEAM (BOM#159)	
160	ROGUEOUTCAST2BEAM/08011973	PTH210200013680	linear prism ROIP-300 BEAM (BOM#160)	
161	ROGUEOUTCAST2BEAM/08011973	PTH040100003688	motor 16HA2048G-50N (BOM#161)	
162	ROGUEOUTCAST2BEAM/08011973	PTH010101012324	light blocker TOUGH-350B-A03-20 (BOM#162)	
163	ROGUEOUTCAST2BEAM/08011973	PTH010101012602	belt light blocker TOUGH-350B-A03-21 (BOM#163)	
164	ROGUEOUTCAST2BEAM/08011973	PTH010101012253	focus motor bracket TOUGH-350B-A03-17 (BOM#164)	
165	ROGUEOUTCAST2BEAM/08011973	PTH0010302003914	standoff H7*50.5 (BOM#165)	
166	ROGUEOUTCAST2BEAM/08011973	PTH010203005317	slider ROIP-140-B03 (BOM#166)	
167	ROGUEOUTCAST2BEAM/08011973	PTH050101004290	focus A152-161 (BOM#167)	
168	ROGUEOUTCAST2BEAM/08011973	PTH010302000094	standoff H6*9 (BOM#168)	

169	ROGUEOUTCAST2BEAM/08011973	PTH010101012327	lens bracket TOUGH-350B-A03-18 (BOM#169)	
170	ROGUEOUTCAST2BEAM/08011973	PTH010203000076	slide cover DJ-3R-B01 (BOM#170)	
171	ROGUEOUTCAST2BEAM/08011973	PTH010101012256	focus front bracket ROIP-140-A03-16 (BOM#171)	
172	ROGUEOUTCAST2BEAM/08011973	PTH010102014566	wiring board TOUGH-350B-A03-27 (BOM#172)	
173	ROGUEOUTCAST2BEAM/08011973	PTH010504000180	head side cover ROIP-300B-D02 (BOM#173)	
174	ROGUEOUTCAST2BEAM/08011973	PTH010101012084	tilt lock block ROIP-140-A02-12 (BOM#174)	
175	ROGUEOUTCAST2BEAM/08011973	PTH070200011851	arm gasket ROIP-140-C03 (BOM#175)	
176	ROGUEOUTCAST2BEAM/08011973	PTH010504000162	arm cover ROIP-140-D02 (BOM#176)	
177	ROGUEOUTCAST2BEAM/08011973	PTH010504000159	lens bracket ROIP-140-D05 (BOM#177)	
178	ROGUEOUTCAST2BEAM/08011973	PTH070200011853	lens gasket ROIP-140-C05 (BOM#178)	
179	ROGUEOUTCAST2BEAM/08011973	PTH050101004291	objective lens A152-161 (BOM#179)	
180	ROGUEOUTCAST2BEAM/08011973	PTH010101012081	lens bracket ROIP-140-A03-10 (BOM#180)	
181	ROGUEOUTCAST2BEAM/08011973	PTH070100004612	lens cover ROIP-140-C01 (BOM#181)	