



SPI Level Translator





Note: Use SPI and Reset to upload sketch to AVR chip.

USB debug



UART Level Shift



Released under the CC Attribution Share-Alike 3.0 License
<http://creativecommons.org/licenses/by-sa/3.0/>

Interface to Dragino2

MODEL: M32.v1.2

2016/4/18 0:25

Sheet: 2/3

