




DEVICE USB




USER LED




MCU




UART




TOUCH




EXTERNAL HSE CLK




EXTERNAL LSE CLK



SWD




BOOT



CONNECT

芯途创科

RESET KEY



USER LED

