





DEVICE USB




SWD





BOOT0




MCU




DC-DC




USER KEY




RF



UART



RESET KEY



USER LED

