









UART to RS232 RJ45 Adaptor

VCC

UART-TX

UART-RX

GND

J1

VCC = 3.3V to 5.5V

UART = CMOS or TTL











