
Part No.	Part Name	QTY
1	Main base	1
2	Lower support brackets	2
3	Load cell	3
4	Secondary Base	1
5	Front support brackets	2
6	Rotor mounting bracket	1
