

LumberJack

Data log control for Saleae Logic

- 1) Make sure you are using the latest version of the Saleae Software, 1.2.5 as of this writing.
- 2) Make sure to enable “scripting socket server”
Options>Preferences>Developer-> make sure the Enable scripting socket server is ticked.
- 3) Run Setup which is found in the “publish” directory on the GitHub repository.
- 4) Start the Saleae Logic 1.2.5 program.
- 5) Set the monitor to your needs, being sure that “scripting socket server” is enabled.
- 6) Launch LumberJack and follow the prompts, using the defaults should create a directory “C:/traces/” for your datalogs.
- 7) You can review your traces with Options>Open capture / setup (or CTRL O)