

Servo

- Eliobot pin
- Power
- Not Connected
- Function
- Ground

