

INSPECT: INelastic Seismic Performance Evaluation Computational Tool

Copyright © 2016, Dr. Mohammad AlHamaydeh et al.
All rights reserved.


Installation Instructions

1. Download the installer file [installer.exe] from the following link:



<https://github.com/alhamaydeh/INSPECT/blob/master/Installer/Installer.exe?raw=true>



Copy and paste the link to your browser to download the file to your local hard drive.



2. Make sure that you uninstalled all previous versions of INSPECT, if applicable.
3. Run the installer by double-clicking on the file.
4. If you get any security warning that the file is downloaded from the internet click “Run.”
The following is an example of the security warning message that may appear; it may look slightly different depending on your OS or/and security programs installed.



5. Follow the installation wizard:









The INSPECT program icon should appear in your desktop, double-click it to run INSPECT

Initial Run Instructions

1. Once INSPECT installation is completed successfully, double-click on the INSPECT icon to run it.
2. Upon first run, INSPECT will display the IDARC-2D license agreement and disclaimers:



3. Upon accepting the IDARC-2D license and disclaimers, the INSPECT license agreement is displayed:



4. Once the IDARC-2D and INSPECT agreements have been accepted, the user will not be promoted subsequently.