



JOYSTICK

JOYSTICK
CABLES

FRONT PANEL
BREAKOUT

UP
Z-BUTTON

DOWN
Z-BUTTON

Z-BUTTON
WIRES

WIRING LOOM