



- Power
 - GND
 - Serial Pin
 - Analog Pin
 - Control
 - Physical Pin
 - Port Pin
 - Touch Pin
 - DAC Pin
 - PMW Pin
- Low Level Bootloader
- P2 + GND
- Boot modes and safe boot
- P12 + 3V3
- 1-3 sec Safe boot, latest firmware is selected
- 4-6 sec Safe boot, previous user update selected
- 7-9 sec Safe boot, the factory firmware is selected

Internal Functions

36	GPI023	VSPID	HS1STROBE	LTE radio TX
27	GPI018	EMAC0180	U2TXD	LTE radio RTS

